Quick Start Guide

1 set

1 set

1

password. You do so using the DW® IP Finder™ software or from the camera's browser menu. WHAT'S IN THE BOX Quick Setup and Installation Bolt and Nuts 2pcs 1 set Screws and Plastic

Mounting Templates 1 Anchors - 2pcs Waterproof Cap and Rubber Rings (Black: Ø0.15" (Ø4mm), White: Ø0.19" (Ø5mm)) Star Wrench (T-20) 1 set

Guide

NOTE: Download all your support materials and tools in one place Go to: http://www.digital-watchdog.com/resources Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.

Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results. Attention: This document is intended to serve as a quick reference for the initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage. SAFETY AND WARNING INFORMATION Read through this Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. See the user manual for more information on the proper installation, use and care of the product. These instructions are intended to ensure that users can use the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected.

Cautions: Injury or equipment damage may occur if any of the cautions are neglected.

IRNING
In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.

Be sure to use only the standard adapter specified in the specification sheet. Using any other adapter could cause fire, electrical shock, or damage to the product.

Make sure the power supply voltage is correct before using the camera. Incorrectly connecting the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product.

Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat generation or fire.

Securely plug the power cord into the power source. An insecure connection may cause a fire.

When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.

Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or electric shock.

Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.

Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.

Do not install near any heat sources such as radiators, heat registers, or other products (including amplifiers) that produce heat.

Keep out of direct sunlight and heat radiation sources. It may cause a fire. WARNING 2. 5. 6 /. 8. 9.

10 11. that produce neat.

Keep out of direct sunlight and heat radiation sources. It may cause a fire.

If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.

When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock. 13. electric shock Use proper safety gear when installing and wiring the product. Do not drop obje

15. CAUTION Keep away from a location subject to excessive Do not drop objects on the production or magnetic interference. Do not use this product near water.

The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product. 5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the 6. 7. 8.

Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the image sensor. The Main plug is used as a disconnect device and shall stay readily operable at any time. Remove the power adapter from the outlet when then there is lightning. Neglecting to do so may cause fire or damage to the product.

Do not block any ventilation openings. Install following the manufacturer's instructions.

A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.

If any laser equipment is used near the product, make sure the surface of the sensor is not exposed to the laser beam as that may damage the sensor module. 10 11. beam as that may damage the sensor module.

If you want to move the already installed product, be sure to turn off the power and then move or reinstall it.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or 12. 13. end-user. end-user.

If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.

Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device 15 from dirt.

Use only attachments/accessories specified by the manufacturer.

Always use hardware (e.g. screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount. 17. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. Unplug this product when a cart is used. Use caution when moving the cart/product combination to avoid injury 18 19. from tip-over 20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped. STEP 1 - PREPARING TO MOUNT THE CAMERA CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. This product is intended to be supplied by a UL Listed Power Supply Unit marked "Class 2" or "LPS" or "PS2" and rated 12 Vdc, 0.31A (DWC-MPV72 and DWC-MV72 series) or 0.5A (DWC-

802-3af shall be a UL Listed device with the output evaluated as a Limited Power Source as defined in UL60950-1 or PS2 as defined in UL62368-1. 4. Unit is intended for installation in a Network Environment O as defined in IEC TR 62102. As such, associated Ethernet wiring shall be limited to inside the building. For the installation process, use the wrench provided with the camera to remove the dome cover from the camera module by loosening the three (3) screws on the dome. Using the mounting template sheet or the camera itself, mark and drill the necessary holes in the wall or ceiling. STEP 2 - POWERING THE CAMERA

> Use non-PoE Switch to connect data using and Ethernet cable and use a

> power adapter to power the camera.

√□ ← □□→{ **१** }•₫:

Power consumption

DC12V: max 3.7W

PoE: max 5.4W

The wired LAN hub providing power over the Ethernet (PoE) in accordance with IEEE

MPV75 and DWC-MV75 series) min.

Use a PoE Injector (required. Sold

separately) to connect data and power to the camera using a single

Ethernet cable.

Models

DWC-MV72Di4TW

CAMERA

DWC-MV72Di28TW

Pass the wires through and make all necessary connections.

WATERPROOF CAP INSTALLATION

3.

DWC-M(P)V75Wi28TW DC 12V, PoE IEEE 802.3af Class3. DC12V: max 6W DWC-M(P)V75Wi4TW (Adapter not included) PoE: max 7.2W DWC-M(P)V75Wi6TW DWC-M(P)V72Wi28ATW DWC-M(P)V72Wi4ATW DC 12V, PoE IEEE 802.3af Class2. DC12V: max 3.7W DWC-M(P)V72Wi28TW (Adapter not included) PoE: max 5.5W DWC-M(P)V72Wi4TW DWC-M(P)V72Wi6TW

Power requirements

OR

network cable's diameter. Cables with ø4.5mm to ø5.5mm thickness should use the black rubber ring. Cables NOTE: over \emptyset 5.5mm in thickness should use the white rubber ring. NOTE: To ensure moisture seal, make sure the o-ring (1) is in place between (2) and (1). In extreme environments use of an outdoor rated sealer is recommended.


RECORDER

SEAL TAPE

DC 12V, PoE IEEE 802.3af Class2.

The waterproof cap set comes with two rubber rings. Use the rubber ring best suited for your

(Adapter not included)



3. The camera is equipped with a manual IR activation button. You can choose to disable the

LED on/off

Mounting Template

X

*Built-in Microphone

Protective Film

camera's IR LEDs when the installation environment requires so.

Remove After Installation

nstallation Remove After Ins

Cameras with a built-in microphone (DWC-M(P)V72Wi28ATW and DWC-M(P) NOTE: V72Wi4ATW) should be installed approximately 3~6ft (1~2 meters) from a person speaking in a normal tone (50~60 dB).

pan and tilt.

camera's base.

Adjust the camera's lens position by rotating the camera on its three-axis gimbal. Use a Philips head screwdriver to loosen the screw at the base of the camera slightly to allow the camera module to move. Using force to rotate the camera's module without loosening the screw may damage the camera. Tighten the screw back after adjusting the camera module's

5. When assembling the dome back on the camera, align the screw holes in the dome and the

6. When the installation is complete, remove the inner protection film and dome's protective film. Softly wipe the dome/lens cover with lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process. NOTE: Be careful not to alter the monitoring direction of your camera.

STEP 4 - MANAGING THE SD CARD

Insert SD Card

Resetting the camera: Press the reset button for five (5) seconds to initiate a camera-wide

reset, including network settings.

STEP 5 - DW® IP FINDER™

Select network to scan-

Scan network
Show/hide thumbnail view
Refresh thumbnail view
Bulk IP assignment
Bulk codec assignment
Bulk date/time assignment
Bulk password assignment

Network Setup

cameras.

the right.

user ID.

Filter results

Scan network

NOTE: Maximum SD Card size supported: Up to 1TB micro SD / FAT32.

be facing upward, as shown in the diagram.

the camera's network settings or access the camera's web client.

To install the DW IP Finder, go to: http://www.digital-watchdog.com Enter "DW IP Finder" on the search box at the top of the page.

5. When connecting to the camera for the first time, a password must be set.

3. Go to the "Software" tab on the DW IP Finder page to download and install the installation file.

supported devices and list the results in the table. During the scan, the DW® logo will turn gray.

a. Check the box next to the camera in the IP Finder's search results. You can select multiple

When inserting the SD card into the card slot, the SD card's contacts should

Use the DW IP Finder software to scan the network and detect all MEGApix® cameras, set

series have an SD card slot at the base of the camera.

2. Insert a class 10 SD card by pressing the SD card slot. 3. Press the card inward to release from the card slot.

Locate the SD card slot in the back of the camera module.

DWC-MPV75Wi series, DWC-MV75Wi series, DWC-MPV72Wi series, and DWC-MV72Wi

Remove SD Card

Reset button

-Firmware version

Camera's uptime

Camera's network information

It will scan the selected network for all

New

Hint

DWC-MF4Wi6C6

00:0D:F1:2B:7B:CE

192.168.21 .144

8.8.8.8

%

Bulk Password Assignment

MAC Address

DWC-MF2Wi4T 00:0D:F1:21:66:92 192.168.10.159

Camera Name

MAC Address

O DHCP

Static IP

Camera Account

Username admin Password •••••••

Current Accou

Username

Password

Camera's name, IP and MAC addresses

Open IP configuration settings

Firmware upgrade W-DIGITAL WATCHDOG

Open the DW IP Finder and click 'Scan Devices

c. Enter admin/admin for the current username and

password. Enter a new username and password to

Passwords must have a minimum of eight (8)

characters and at least four (4) combinations of

uppercase and lowercase letters, numbers and special characters. Passwords cannot contain the

6. Select a camera from the list by double-clicking on the camera's name or clicking on the 'Click' button.

The pop-up window will show the camera's current

network settings. Admin users can adjust the settings

the username and password of the camera's admin

account and click 'Apply'.

information.

router.

STEP 6 - WEB VIEWER

b. Click "Bulk Password Assign" on the left.

d. Click "change" to apply all changes.

as needed. The camera's network settings are set to IP Address DHCP by default. To access the camera's web page, click on the 'Website' button. 8. To save changes made to the camera's settings, enter DNS

1 The camera's IP must be set to static if connecting to Spectrum® IPVMS.

Contact your network administrator for more information.

f Select 'DHCP' for the camera to automatically receive its IP address from the DHCP server. 🚺 Select 'Static' to manually enter the camera's IP address, (Sub)Netmask, Gateway and DNS

🌓 To access the camera from an external network, port forwarding must be set in your network's

- *The GUI display may differ by camera models. Find the camera using the DW IP Finder. 2. Double-click on the camera's view in the results table. Press the 'View Camera Website'. 4. Enter the camera's username and password you setup in the DW IP Finder. If you did not setup a new username and password, a message will direct you to setup a new password for the camera to view the video. @ http://192.168.10.159/ - IP Camera - Internet Explorer Change admin's password [Type the Password]
 - Password requirement : minimum 8 characters with at least three combinations of uppercase letters, lowercase letters, numbers and special characters. Acceptable special characters are; $\sim 1\$ () |\{\}[]$; . ? /

 $\label{eq:copyright @ Digital Watchdog. All rights reserved.} Specifications and pricing are subject to change without notice.$

digital-watchdog.com

CHANGE PASSWORD CHANGE LATER 5. When accessing the camera for the first time, install the VLC player for web files to view video from the camera. NOTE: Please see the full product manual for web viewer setup, functions and camera settings options.

NOTE: This products is covered by one or more claims of the HEVC Patents

Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

listed at patentlist.accessadvance.com.

Tel: +1 (866) 446-3595 / (813) 888-9555

Rev: 01/25